

ColoQuick MAXX4 + Pasteur

STANDARD PROGRAM SETTINGS

MAX COOLING PASTEURIZATION	ENERGY SAVING PASTEURIZATION
PROGRAMMING MENU CODE 1110	PROGRAMMING MENU CODE 1111
PASTEURIZE [1] Enabled: YES Protected: NO Code: 0000	PASTEURIZE [2] Enabled: YES Protected: NO Code: 0000
PASTEURIZE Per. [1] Temp: 61.8 Time: 005m Interval Speed: 06 ON: 020s OFF: 240s	PASTEURIZE Per. [1] Temp: 61.8 Time: 005m Interval Speed: 06 ON: 020s OFF: 240s
PASTEURIZE Per. [2] Temp: 60.0 Time: 060m Interval Speed: 06 ON: 020s OFF: 600s	PASTEURIZE Per. [2] Temp: 60.0 Time: 060m Interval Speed: 06 ON: 020s OFF: 600s
PASTEURIZE Per. [3] Temp: 00.0 Time: 008m Interval Speed: 06 ON: 020s OFF: 240s	PASTEURIZE Per. [3] Temp: 37.5 Time: 008m Interval Speed: 06 ON: 020s OFF: 240s
PASTEURIZE Per. [4] Temp: 00.0 Time: 1440 Interval Speed: 06 ON: 020s OFF: 600s	PASTEURIZE Per. [4] Temp: 42.0 Time: 1440 Interval Speed: 06 ON: 020s OFF: 600s



**STANDARD
THAW**

PROGRAMMING
MENU CODE 1120

THAW [1]
Enabled: YES
Protected: NO
Code: 0000

THAW Per.[1]
Temp:42.0 Time:000m
Interval Speed: 06
ON: 010s OFF: 000s

THAW Per.[2]
Temp:42.0 Time:020m
Interval Speed: 10
ON: 010s OFF: 000s

THAW Per.[3]
Temp:42.0 Time:000m
Interval Speed: 06
ON: 010s OFF: 000s

THAW Per.[4]
Temp:42.0 Time:1440
Interval Speed: 06
ON: 010s OFF: 045s

**EXTRA
THAW**

PROGRAMMING
MENU CODE 1121

THAW [2]
Enabled: YES
Protected: NO
Code: 0000

THAW Per.[1]
Temp:44.0 Time:000m
Interval Speed: 06
ON: 010s OFF: 000s

THAW Per.[2]
Temp:44.0 Time:020m
Interval Speed: 10
ON: 010s OFF: 000s

THAW Per.[3]
Temp:42.0 Time:005m
Interval Speed: 06
ON: 020s OFF: 040s

THAW Per.[4]
Temp:42.0 Time:1440
Interval Speed: 06
ON: 010s OFF: 045s

